

Funny


Cod. 10018

Funny P.C.


Cod.	Pos.	€	Cod.	Pos.	€
10204	01		10103	021	
30291	1a		30313	22	
30292	2		30314	23	
30293	3		30316	25	
30294	4		30317	26	
30296	6		30325	26a	
30297	7		30319	27	
30298	8		30320	28	
30299	9		30321	28a	
30300	10		30324	31	
30301	11				
30302	11a *				
30303	12 *				
30304	13 *				
30305	13a *				
30306	14 *				
10100	017 *				
30308	17a				
10101	019 *				
30311	20				

* Ricambi consigliati / Recommended spare parts
Empfohlene Ersatzteile / Repuestos recomendados / Pièces de rechange recommandées



Pos. 017



Pos. 021



Pos. 019



Cod. 10019

Funny F.C.

* Ricambi consigliati / Recommended spare parts
Empfohlene Ersatzteile / Repuestos recomendados / Pièces de rechange recommandées

Cod.	Pos.	€	Cod.	Pos.	€
10205	01		30321	28a	
30291	1a		30324	31	
30292	2		30325	32	
30293	3				
30294	4				
30296	6				
30297	7				
30298	8				
30299	9				
30300	10				
30301	11				
30302	11a *				
30303	12 *				
30304	13 *				
30305	13a *				
30306	14 *				
10100	017 *				
30308	17a				
30319	27				
30320	28				

