


Jolly

Cod. 10124

Jolly P.C.

Cod.	Pos.	€	Cod.	Pos.	€
10200	01		10202	020	
10243	02		30322	20a	
30344	3		30704	21	
30345	4		30366	22	
30347	6		30368	24	
30348	7		10429	025	
30349	8		30325	25a	
30350	9		30369	26	
30300	10		30370	27	
30351	10a		30321	27a	
30352	11 *		30280	28	
30354	12 *		10105	029	
30355	12a *		30371	30	
30356	13 *		30372	32	
30357	14 *		30373	34	
10108	015 *		30336	35	
30359	16		30337	36	
10109	018 *		30374	37	
30702	19		3010183	38	

* Ricambi consigliati / Recommended spare parts /
Empfohlene Ersatzteile / Repuestos recomendados /
Pièces de rechange recommandées



Cod. 10125

Jolly F.C.

* Ricambi consigliati / Recommended spare parts / Empfohlene Ersatzteile
Repuestos recomendados / Pièces de rechange recommandées

Cod.	Pos.	€	Cod.	Pos.	€
10203	01		30321	27a	
10243	02		30280	28	
30344	3		10105	029	
30345	4		30371	30	
30347	6		30372	32	
30348	7		30373	34	
30349	8		30336	35	
30350	9		30337	36	
30300	10		30374	37	
30351	10a				
30352	11 *				
30354	12 *				
30355	12a *				
30356	13 *				
30357	14 *				
10108	015 *				
30359	16				
30369	26				
30370	27				

